


# Career<sup>®</sup>

## 安装、使用和维护说明手册 Installation, Operation, and Maintenance Manual

### CX20



# Career<sup>®</sup>



ISO9001:2015  
Quality System  
Certification

该目录仅供参考。保留根据技术进步进行更改的权利。

This directory is for reference only. Reserves the right to change to accommodate technological advances.

ISO 9001认证：符合国际质量管理体系标准，确保产品的高品质与可靠性。

ISO 9001 Certification: Complies with international quality management system standards, ensuring high quality and reliability of the product.

# — 目录

|                         |    |
|-------------------------|----|
| 1. 安全警告 .....           | 01 |
| 2. 产品参数与技术规范 .....      | 02 |
| 工作曲线图 .....             | 02 |
| 组件 .....                | 03 |
| 安装尺寸 .....              | 04 |
| 包装参数 .....              | 04 |
| 3. 安装与调试 .....          | 05 |
| 安装前准备 .....             | 05 |
| 燃烧器安装 .....             | 06 |
| 燃料系统连接 .....            | 07 |
| 电气接线图 .....             | 10 |
| 燃料供给与雾化原理 → 启动准备 .....  | 13 |
| 首次启动操作 .....            | 14 |
| 强制鼓风与空燃比原理 → 点火准备 ..... | 16 |
| 点火与稳焰原理 → 首次点火执行 .....  | 17 |
| 4. 操作与维护 .....          | 18 |
| 启动步骤 .....              | 18 |
| 火焰调节与安全监控 .....         | 19 |
| 停机操作 .....              | 19 |
| 5. 服务与维护 .....          | 20 |
| 点火电极与稳焰盘设置 .....        | 20 |
| 日常注意事项 .....            | 21 |
| 维修周期表 .....             | 21 |
| 燃烧器内部清洁 .....           | 21 |
| 6. 故障与排除方法 .....        | 22 |
| 7. 装箱清单 .....           | 23 |
| 8. 零件图 .....            | 24 |

## 1. 安全警告

| 风险类型 | 操作禁令         | 强制措施               |
|------|--------------|--------------------|
| 电气安全 | × 超10A保险丝    | ✓ 独立断路器+每月接地检测     |
| 高温防护 | × >40°C接触燃烧器 | ✓ 停机后风机持续散热        |
| 燃料泄漏 | × 明火/通电状态检修  | ✓ 立即关阀→通风→肥皂水检漏/吸附 |
| 无人值守 | × 未装双保险恒温器运行 | ✓ 主控+保险温控串联安装      |

致命项：带电维护点火电极=触电风险！


## 2. 产品参数与技术规范

| 项目    | 参数值  |
|-------|--|
| 型号    | CX20   |
| 额定热功率 | 71~237 kW  |
| 燃料类型  | 轻柴油(黏度3-6cSt@20°C), 兼容:<br>➢ 煤油(需采用双油管系统)<br>➢ 符合 DIN V 51603-6 EL A Bio-10 标准的生物燃油(最大 10% FAME) |
| 耗油量   | 6-17.3 kg/h (炉膛内压0时)   |
| 电源规格  | 220V±10%, 50Hz, IP55   |
| 调节方式  | 开关式  |


注:

- 使用煤油或生物燃油时需采用双油管系统;
- 长期使用生物燃油可能缩短油泵寿命, 建议定期检查过滤器。

## 工作曲线图





▶ 组件



| 序号 | 部件名称   | 技术规格/位置             | 功能说明与维护指引  |
|----|--------|---------------------|--|
| 1  | 火通     | Φ108mm              | 火焰通道   注意高温，禁止触碰                                     |
| 2  | 点火变压器  | 输出2*5kV   50Hz      | 高压电弧点火   |
| 3  | 控制器    | 工作温度-10~50°C        | 系统逻辑控制   |
| 4  | 故障复位按钮 | -                   | 手动复位报警   |
| 5  | 电机     | 220V/0.18kW 2800rpm | 驱动风机   |
| 6  | 喷嘴油枪组合 | 雾化角60°              | 燃油雾化核心   每3000小时强制更换                                 |
| 7  | 火焰检测器  | 感光电眼                | 实时监测火焰   每月清洁  |
| 8  | 风门执行器  | 开度0-90°             | 空气流量调节   高/低负荷需重新标定<br>(参考“强制鼓风与空燃比原理理 → 点火准备”P16章节) |
| 9  | 电磁阀    | 常闭型                 | 燃油通断控制   |
| 10 | 油泵     | 最大压力14bar   单双油管适配  | 燃油加压   禁止空转<br>(单油管系统需手动排气)                          |

▶ 安装尺寸



| 单位mm | A   | B    | C    | D   | E   | F  | G   | H   | 到地板最小距离 |
|------|-----|------|------|-----|-----|----|-----|-----|---------|
| 标准型  | 115 | Φ104 | Φ108 | 372 | 220 | 83 | 175 | 207 | 200     |
| 加长型1 | 187 |      |      |     |     |    |     |     |         |

▶ 包装参数

| 型号   |      | 包装尺寸 (长×宽×高)  | 净重   | 毛重   |
|------|------|---------------|------|------|
| CX20 | 标准型  | 545×455×360mm | 14kg | 17kg |
|      | 加长型1 | 625×455×360mm | 15kg | 18kg |


### 3. 安装与调试

#### ▶ 安装前准备

- 检查运输完整性，报告损坏。
- 确保安装环境干燥、无化学品，相对湿度 $\leq 80\%$ 。
- 准备工具（标配工具随机附带，其余需客户自备）：


| 工具名称                  | 属性 | 用途                            |
|-----------------------|----|-------------------------------|
| 六角扳手                  | 自备 | 安装法兰螺栓紧固<br>(请根据所选螺栓尺寸配置相应扳手) |
| 8-10mm六角螺丝及配套垫片       | 自备 | 安装法兰螺栓紧固(请根据实际炉口尺寸选择)         |
| 17号六角扳手               | 自备 | 软油管接口连接                       |
| 5mm六角匙                | 自备 | 风门-喷嘴位置调节                     |
| 1号一字螺丝刀               | 自备 | 控制器接线座脱离(推弹簧)/油泵排气螺钉操作        |
| 4mm六角匙                | 标配 | 安装法兰固定/油泵调压/风门调整              |
| 油压表 扬程0-20bar, G1/8接口 | 自备 | 油泵压力监测                        |
| 绝缘胶带 PVC电工胶带          | 自备 | 电气接线绝缘                        |
| 密封胶耐油型                | 自备 | 油管接口密封                        |

#### ▶ 燃烧器安装




- 将法兰与石棉垫固定在锅炉接口。
- 燃烧器主体对准法兰，用螺栓紧固。
- 连接油管、电源线（按接线图操作）。

▶ 燃料系统连接



| 系统类型 | 适用场景            | 核心区别              | 油泵操作                |
|------|-----------------|-------------------|---------------------|
| 单油管  | 油箱位置高于燃烧器       | 无回油管, 首次使用必须手动排气。 | 拆除油泵内部回路螺丝D, 安装铁塞。  |
| 双油管  | 油箱位置低于燃烧器 或使用煤油 | 含供油管+回油管, 自动循环。   | 保留油泵内部回路螺丝D, 连接回油管。 |

油泵内部调整



操作工具:

▶ 4mm六角钥匙(随机附带)

强制要求: 回油管需高于油箱最高液面, 避免虹吸倒流。 ⚠

### 1. 排气说明

单油管系统：在首次启动前，打开油泵压力表接口（G1/8）排气，直至燃油无泡沫流出。

### 2. 安装顺序



### 3. 密封性检查

- (1) 打开球阀，启动油泵（不点火），观察各接口是否渗油。
- (2) 若泄漏，重新拧紧或更换密封垫片。

### 4. 关键注意事项


- 安装顺序不可逆：燃油必须先经过球阀控制流量，再通过过滤器净化，最后经软油管进入油泵。
- 垫片强制安装：软油管连接油泵端接口必须安装密封垫片，否则可能引发泄漏。

### 5. 维护提示

过滤器每1个月清洁一次，每年更换滤芯（参考“服务与维护” P20章节）。


## 电气接线图

### 控制盒接线图（凯利 \*KYLOA24.171B27H 电子式）



| 标识 | 名称                  | 标识 | 名称      |
|----|---------------------|----|---------|
| A1 | *KYLOA24.171B27H电子式 | P1 | 操作时间记录计 |
| A2 | 恒温器                 | H1 | 故障信号灯   |
| S3 | 电源开关                | H2 | 操作信号灯   |
| R1 | 火焰检测(感光电眼)          | F1 | 保险丝     |
| T1 | 点火变压器               | X1 | 接线插座    |
| M1 | 燃烧器电机               | X2 | 电源插头    |
| Y1 | 油泵电磁阀               |    |         |


### 控制盒接线图(霍尼韦尔 TF834E.3)



| 标识 | 名称          | 标识 | 名称      |
|----|-------------|----|---------|
| A1 | TF834E.3控制器 | P1 | 操作时间记录计 |
| A2 | 恒温器         | H1 | 故障信号灯   |
| S3 | 电源开关        | H2 | 操作信号灯   |
| R1 | 火焰检测(感光电眼)  | F1 | 保险丝     |
| T1 | 点火变压器       | X1 | 接线插座    |
| M1 | 燃烧器电机       | X2 | 电源插头    |
| Y1 | 油泵电磁阀       |    |         |

### 重点安全配置说明

#### 双保险恒温器



#### 结构原理:

#### 内置串联的两个独立温控单元:

- 主恒温器: 设定工作温度(例:80°C)。
- 保险恒温器: 设定安全温度(=主设定+15~20°C, 例:95°C)。

安全逻辑: 当主恒温器失效时, 炉温升至安全温度自动切断电源。

#### 保险丝规格

#### 最大电流:

- 10A

#### 违规后果:

过流可能导致控制器烧毁引发火灾。

#### 故障信号灯

#### 安装位置:

- 操作间醒目墙面(非控制盒指示灯)。

#### 核心价值:

- 即时识别E01-E10故障代码, 避免事故扩大。

#### 操作信号灯

#### 功能:

- 绿色常亮=运行中, 熄灭=停机。

#### 接线端:

- 凯利 KYLOA24.171B27H 电子式控制器: 端子 N和 8
- 霍尼韦尔 TF834E.3 控制器: 端子 6 和 8

#### 操作时间记录计

#### 作用:


- 累计燃烧小时数(维护周期依据)。

#### 数据应用:

- 每500小时清洁油泵滤网
- 每3000小时更换喷嘴。

## ▶ 燃料供给与雾化原理 → 启动准备

### 🌀 工作原理




燃油经油泵加压至10bar，通过机械雾化喷嘴形成锥形油雾，与空气充分混合后形成可燃混合气。

### 🌀 喷嘴选型与热功率优化指南

喷嘴选型黄金法则

喷嘴尺寸（GPH值）直接决定燃油雾化质量和燃烧强度：



➤ GPH定义：美加仑/小时（1 GPH = 3.785升/小时）（7bar油压下）

➤ 核心影响：每增加0.25 GPH，功率提升约11kW（10bar油压下）

### 🌀 喷嘴选型对照表

| GPH  | 7 bar |         | 8 bar |         | 9 bar |         | 10 bar |         | 11 bar |         | 12 bar |         | 13 bar |         | 14 bar |         |
|------|-------|---------|-------|---------|-------|---------|--------|---------|--------|---------|--------|---------|--------|---------|--------|---------|
|      | kg/h  | kW      | kg/h  | kW      | kg/h  | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      |
| 1.75 | 5.15  | 61/60   | 5.51  | 65/64   | 5.85  | 69/68   | 6.15   | 73/72   | 6.45   | 76/75   | 6.73   | 80/78   | 7.01   | 83/82   | 7.28   | 86/85   |
| 2.00 | 5.89  | 70/69   | 6.29  | 75/73   | 6.68  | 79/78   | 7.03   | 83/82   | 7.37   | 87/86   | 7.69   | 91/90   | 8.01   | 95/93   | 8.32   | 99/98   |
| 2.25 | 6.62  | 78/77   | 7.08  | 84/82   | 7.52  | 89/88   | 7.91   | 94/93   | 8.29   | 98/97   | 8.65   | 103/101 | 9.01   | 107/105 | 9.36   | 111/109 |
| 2.50 | 7.36  | 87/86   | 7.87  | 93/92   | 8.36  | 99/97   | 8.79   | 104/103 | 9.21   | 109/107 | 9.61   | 114/112 | 10.11  | 119/117 | 10.411 | 123/121 |
| 2.75 | 8.10  | 96/95   | 8.66  | 103/101 | 9.20  | 109/107 | 9.68   | 115/113 | 10.14  | 120/118 | 10.58  | 125/123 | 11.02  | 131/128 | 11.46  | 136/133 |
| 3.00 | 8.83  | 105/104 | 9.44  | 112/110 | 10.03 | 119/117 | 10.55  | 125/123 | 11.06  | 131/129 | 11.54  | 137/134 | 12.02  | 143/140 | 12.49  | 148/145 |
| 3.50 | 10.3  | 122/121 | 11.02 | 131/128 | 11.71 | 139/136 | 12.31  | 146/143 | 12.9   | 153/150 | 13.46  | 160/157 | 14.02  | 166/163 | 14.57  | 173/170 |
| 4.00 | 11.78 | 140/137 | 12.59 | 149/147 | 13.38 | 159/156 | 14.07  | 167/164 | 14.74  | 167/164 | 15.39  | 182/179 | 16.03  | 190/187 | 16.66  | 198/194 |
| 4.50 | 13.25 | 157/154 | 14.17 | 168/165 | 15.06 | 179/175 | 15.83  | 188/184 | 16.59  | 197/193 | 17.32  | 205/202 | 17.32  | 214/210 | 18.74  | 222/218 |

注：

➤ GPH：美制加仑/小时。1 GPH = 3.785 升/小时（在 7 bar 油压下）。

➤ 功率格式：柴油功率 / 煤油功率（例：64/59 = 柴油64 kW, 煤油59 kW）。

➤ 热值计算基础：

■ 柴油：11.86 kWh/kg

■ 煤油：11.75 kWh/kg（约为柴油的0.92倍）。

➤ 流量-压力关系：流量与压力的平方根成正比。

➤ 计算公式： $Q_2 = Q_1 \times \sqrt{P_2/P_1}$

➤ 重要提示：实际使用中请根据炉膛背压、烟囱阻力、燃油品质等因素适当调整喷嘴选型。实际功率可能存在 ±5% 的浮动。

## ▶ 首次启动操作

### 🌀 油路系统检查

➤ 单油管系统：

1. 拆除回油螺丝 → 安装铁塞

2. 打开压力表接口

3. 启动油泵至无泡沫燃油流出

➤ 双油管系统：保留回油螺丝 → 连接回油管至油箱顶部。

### 🌀 油压调节


➤ 重要警示：油泵出厂预设10±0.5bar，仅当安装环境特殊（如超高/低温）或更换喷嘴后允许微调。违规操作将导致保修失效！

### 调节流程

| 步骤 | 操作          | 精度要求          | 风险控制措施        |
|----|-------------|---------------|---------------|
| 1  | 4mm六角匙微调螺钉  | 单次调节≤1/4圈     | 调节后稳定运行30秒再检测 |
|    | 顺时针(增压)     | 每1/4圈≈+0.5bar | 严禁超过14bar红线   |
|    | 逆时针(减压)     | 每1/4圈≈-0.5bar | 严禁低于燃烧器最小设计压力 |
| 2  | 10±0.5bar锁定 | 波动值≤0.3bar    | -             |

### 特殊工况补偿表 (参考)

| 环境条件      | 建议油压补偿值      | 依据      |
|-----------|--------------|---------|
| 海拔>1000m  | +0.3bar/500m | 大气压衰减补偿 |
| 油温<0°C    | +0.2bar/5°C  | 黏度增加补偿  |
| 使用生物燃油/煤油 | -0.3bar      | 降低喷嘴磨损  |
| 长油管>5m    | +0.5bar      | 管路压损补偿  |




| 符号 | 功能    | 接口尺寸      |
|----|-------|-----------|
| S  | 吸油口管路 | G 1/4     |
| R  | 回程管路  | G 1/4     |
| E  | 喷嘴出口  | G1/8      |
| P  | 压力表接  | G1/8      |
| V  | 真空表端口 | G1/8      |
| P1 | 压力调整  | 用4mm内六角操作 |
| H  | 过滤器   | -         |


### 强制鼓风与空燃比原理 → 点火准备

#### 首次点火设置

##### 风门—喷嘴协同位置校准



风门调校




喷嘴油枪组合调校

请松开螺丝(B), 并通过螺丝(A)调整喷嘴油枪组合的位置, 以确保良好燃烧。

| 负荷工况  | 喷嘴位置  | 风门位置                 | 验证火焰      |
|-------|-------|----------------------|-----------|
| 高负荷   | 前移    | 逐步增大开度               | 亮白色无黑烟    |
| 低负荷   | 后移    | 逐步减小开度               | 橙黄色不闪烁    |
| 50%负荷 | 保持基准位 | 开度调至50% (旋转刻度盘至"8"位) | 火焰平稳过渡无突变 |

## ▶ 点火与稳焰原理 → 首次点火执行

### 🌀 工作原理



### 🌀 标准点火序列

| 步骤 | 操作    | 等待/验证 | 成功标志    |
|----|-------|-------|---------|
| 1  | 电源接通  | 风机运转  | 黄灯闪烁    |
| 2  | 前吹扫阶段 | ≥10秒  | 排气风声稳定  |
| 3  | 电极放电  | "啪啪"声 | 蓝色电弧可见  |
| 4  | 燃油喷射  | 柴油味   | 喷嘴油雾喷出  |
| 5  | 火焰建立  | 持续10秒 | 橙黄色稳定火焰 |

### 🌀 点火失败处理

| 故障现象   | 立即操作     | 根本原因排查                       |
|--------|----------|------------------------------|
| 无电弧    | 急停→等待50秒 | 1. 检查点火变压器接线<br>2. 测量高压包输出   |
| 有电弧无火焰 | 急停→等待50秒 | 1. 油压检测 (≥8bar)<br>2. 喷嘴堵塞检查 |
| 爆燃     | 急停→通风    | 1. 风门开度过小<br>2. 前吹扫时间不足      |

安全守则 故障复位后操作：  
必须等待50秒才能重启燃烧器，确保燃烧室内残余油气完全散逸

## 4. 操作与维护

### ▶ 启动步骤

#### 步骤1：预检

- 检查油箱油量 (≥1/3容量)，油路阀门处于开启状态。
- 确认电源线连接牢固，无裸露线头。

#### 步骤2：通电启动

- 打开燃烧器电源开关，燃烧器自动执行以下流程：
  - (1) 风机启动，运行≥10秒基础送风；
  - (2) 点火电极放电，油泵通电喷油；
  - (3) 火焰稳定后进入持续运行状态。

➢ 观察控制盒指示灯：  
控制器状态指示灯说明

| 指示灯    | 状态         | 含义             |
|--------|------------|----------------|
| 绿灯常亮 ● | 燃烧器正常运行    | 火焰稳定，系统无故障     |
| 红灯常亮 ● | 故障报警(需处理)  | 查看故障代码并排除      |
| 黄灯闪烁 ● | 吹扫或分控模式运行中 | 无需干预，待流程结束自动切换 |

只适用于：控制器 (Career \*KYLOA24.171B27H 电子式)

## ▶ 火焰调节与安全监控

- ▶ 火焰观察：通过观测孔确认火焰呈橙黄色，稳定无黑烟，根部无飘动。
- ▶ 异常处理：
  - 火焰闪烁：可能因风门开度不匹配或喷嘴堵塞；
  - 黑烟：需检查风门开度或更换喷嘴；
  - 若运行中红灯亮起，立即切断电源与油路。

### 燃烧调节黄金法则

#### 升负荷操作

1. 风门调整：逐步增大开度（每次+1刻度）；
2. 喷嘴位置：向后滑动2-3mm；
3. 验证标准：
  - 火焰呈亮白色
  - 烟囱无黑烟
4. 稳定时间：每次调整后需稳定运行30秒

#### 降负荷操作


1. 风门调整：逐步减小开度（每次-1刻度）
2. 喷嘴位置：向前滑动1-2mm
3. 验证标准：
  - 火焰呈橙黄色
  - 无闪烁现象
4. 稳定时间：每次调整后需稳定运行30秒

## ▶ 停机操作

1. 关闭燃烧机电源总开关；
2. 长期停用时，关闭油路阀门。

## 5. 服务与维护

### ▶ 点火电极与稳焰盘设置



| 标识 | 说明       | 尺寸值          | 备注               |
|----|----------|--------------|------------------|
| A  | 点火电极间隙   | 3.0 - 4.0 mm | 确保火花稳定（火花不接触稳焰盘） |
| B  | 电极至喷嘴距离  | 9.0 mm       |                  |
| C  | 电极至喷嘴前端  | 4.0 - 6.0 mm | 影响火焰根部稳定性        |
| D  | 稳焰盘至喷嘴前端 | 5.0 mm       | 确保油雾在最佳位置点燃      |

## ▶ 日常注意事项

- ▶ 定期清洗油过滤器(每1000小时或每月)。
- ▶ 保持火焰传感器清洁,避免误报故障。
- ▶ 每月检查油箱底部水分与杂质。

## ▶ 维修周期表

| 部件   | 每天     | 每月     | 每年   |
|------|--------|--------|------|
| 过滤器  | 检查渗漏   | 清洗滤网   | 更换滤芯 |
| 点火电极 | 观察放电火花 | 清除积碳   | 更换电极 |
| 喷嘴   | -      | 检查雾化形状 | 强制更换 |
| 油压   | 启动前看表显 | 校准压力表  | -    |

## ▶ 燃烧器内部清洁

- ▶ 清洁风扇叶轮、电极区域、喷嘴残留。
- ▶ 使用软布擦拭,避免损坏绝缘部件。


## 6.故障与排除方法

| 故障代码 | 现象              | 可能原因                            | 解决方案                            |
|------|-----------------|---------------------------------|---------------------------------|
| E01  | 点火失败            | 油压不足、<br>电极偏移                   | 检查油泵压力 (10 bar) ,<br>调整电极       |
| E02  | 燃烧黑烟            | 风门过小、<br>喷嘴堵塞                   | 增大风门,清洁/更换喷嘴。<br>检查风门开度与喷嘴位置匹配性 |
| E03  | 频繁停机            | 火焰信号不稳定                         | 检查传感器线路与控制盒                     |
| E04  | 无燃油喷出           | 油管/喷嘴堵塞、<br>泵故障、<br>电磁阀卡死       | 清理过滤器,检修油泵                      |
| E05  | 噪音过大            | 风门过大、<br>联动轴偏心、<br>电机损坏         | 调小风门,更换联动轴组件,<br>更换电机           |
| E06  | 风门刻度指示<br>与开度不符 | 刻度盘松动、<br>机械连杆磨损、<br>长期使用导致标记褪色 | 紧固刻度盘固定螺丝,更换<br>磨损连杆部件,重新标记刻度   |
| E07  | 油压异常            | 油泵磨损、<br>调节阀松动、<br>过滤器堵塞        | 执行P15校准流程                       |
| E08  | 油压高于14 bar      | 调节阀过紧、<br>回油管堵塞                 | 逆时针调整压力调节阀,<br>清理回油管路           |
| E09  | 风机电源无响应         | 断路器跳闸                           | 复位断路器,检查线路                      |
| E10  | 黄灯常常亮           | 控制盒程序错误                         | 断电重启,检修控制器                      |

## 7. 装箱清单

| 序号 | 名称            | 数量 |
|----|---------------|----|
| 1  | 燃烧器           | 1台 |
| 2  | 安装法兰          | 1个 |
| 3  | 石棉垫           | 1块 |
| 4  | 喷嘴匙           | 1个 |
| 5  | 油管 (1米, 接口2分) | 2条 |
| 6  | 螺丝            | 若干 |
| 7  | 4mm六角钥匙       | 1把 |
| 8  | 过滤器           | 1个 |
| 9  | 说明书           | 1本 |

## 8. 零件图



## — Contents

|  |    |                         |    |
|--|----|-------------------------|----|
| 1. Safety Warnings.....  | 25 | 6. Troubleshooting..... | 47 |
| 2. Product Parameters and Technical Specifications.....            | 26 | 7. Packing List.....    | 48 |
| Performance Curve Diagram .....                                    | 26 | 8. Parts Diagram.....   | 49 |
| Components.....  | 27 |                         |    |
| Installation Dimensions .....                                      | 28 |                         |    |
| Packaging Specifications .....                                     | 28 |                         |    |
| 3. Installation and Commissioning.....                             | 29 |                         |    |
| Pre-Installation Preparation.....                                  | 29 |                         |    |
| Burner Installation .....  | 30 |                         |    |
| Fuel System Connection .....                                       | 31 |                         |    |
| Electrical Wiring Diagrams .....                                   | 34 |                         |    |
| Fuel Supply and Atomization Principles → Startup Preparation ..... | 37 |                         |    |
| Initial Startup Operation.....                                     | 38 |                         |    |
| Forced Draft & Air-Fuel Ratio → Ignition Prep .....                | 40 |                         |    |
| Ignition & Flame Stabilization → Initial Ignition.....             | 41 |                         |    |
| 4. Operation & Maintenance .....                                   | 43 |                         |    |
| Startup Procedure .....  | 43 |                         |    |
| Flame Adjustment & Safety Monitoring .....                         | 44 |                         |    |
| Shutdown Procedure .....   | 44 |                         |    |
| 5. Service & Maintenance.....                                      | 45 |                         |    |
| Ignition Electrode & Brake Plate Settings .....                    | 45 |                         |    |
| Routine Maintenance Notes .....                                    | 46 |                         |    |
| Maintenance Schedule .....   | 46 |                         |    |
| Burner Internal Cleaning .....                                     | 46 |                         |    |



## 1. Safety Warnings

| Risk Type                   | Prohibited Actions                       | Mandatory Measures  |
|-----------------------------|--|---|
| <b>Electrical Safety</b>    | × Exceeding 10A fuse                     | ✓ Dedicated circuit breaker + monthly ground test           |
| <b>High-Temp Protection</b> | × Touching burner >40°C                  | ✓ Post-shutdown continuous fan cooling                      |
| <b>Fuel Leakage</b>         | × Repair with open flame/ power on       | ✓ Shut valve → Ventilate → Soap water leak test/ adsorption |
| <b>Unattended Operation</b> | × Running without dual-safety thermostat | ✓ Install main + backup thermostat in series                |

*Fatal risk: Live maintenance of ignition electrodes = electric shock hazard!*


## 2. Product Parameters and Technical Specifications

| Item                       | Specification   |
|----------------------------|---|
| <b>Model</b>               | CX20  |
| <b>Rated Thermal Power</b> | 71~237 kW   |
| <b>Fuel Type</b>           | Light diesel (viscosity 3–6cSt@20°C), compatible with:<br>➤ Kerosene (requires double-pipe system)<br>➤ Biofuel meeting DIN V 51603-6 ELA Bio-10 (max 10% FAME) |
| <b>Fuel Consumption</b>    | 6-17.3 kg/h (at 0 furnace pressure)   |
| <b>Power Supply</b>        | 220V±10%, 50Hz, IP55  |
| <b>Control Mode</b>        | On/Off  |


Notes:

- Double-pipe system required for kerosene/biofuel.
- Long-term biofuel use may shorten pump life; inspect filters regularly.

### Performance Curve Diagram



## Components



| No. | Component            | Specs/Location                             | Function & Maintenance   |
|-----|----------------------|--|--|
| 1   | Flame Tube           | Φ108mm                                     | Flame channel High temp; no touch                                |
| 2   | Ignition Transformer | Output 2×5kV 50Hz                          | High-voltage arc ignition  |
| 3   | Controller           | Operating temp -10~50°C                    | System logic control   |
| 4   | Fault Reset Button   | —  | Manual alarm reset   |
| 5   | Motor                | 220V/0.18kW 2800rpm                        | Drives fan   |
| 6   | Nozzle Assembly      | 60° spray angle                            | Fuel atomization core<br>  Replace every 3000 hours              |
| 7   | Flame Detector       | Photocell sensor                           | Real-time flame monitoring<br> Clean monthly                     |
| 8   | Damper Actuator      | 0–90° opening                              | Airflow adjustment   Recalibrate for high/low load (see P40)     |
| 9   | Solenoid Valve       | Normally closed                            | Fuel on/off control  |
| 10  | Fuel Pump            | Max 14bar   Double-pipe / Single-pipe line | Fuel pressurization   No dry run (bleed Single-pipe line system) |

## Installation Dimensions

CX20 Mounting Flange

| Unit mm    | A   | B    | C    | D   | E   | F  | G   | H   | Min. Floor Distance |
|------------|-----|------|------|-----|-----|----|-----|-----|---------------------|
| Standard   | 115 | Φ104 | Φ108 | 372 | 220 | 83 | 175 | 207 | 200                 |
| Extended 1 | 187 |      |      |     |     |    |     |     |                     |

## Packaging Specifications

| Model |            | Packaging dimensions (length × width × height) | Net weight | Gross weight |
|-------|------------|--|------------|--------------|
| CX20  | Standard   | 545×455×360mm                                  | 14kg       | 17kg         |
|       | Extended 1 | 625×455×360mm                                  | 15kg       | 18kg         |


## 3. Installation and Commissioning

### ▶ Pre-Installation Preparation

- Inspect shipment integrity; report damage.
- Ensure dry, chemical-free environment; humidity ≤80%.
- Prepare tools (standard tools provided with burner, others require user preparation):


| Tool                                     | Source   | Purpose   |
|--|----------|---|
| hex wrench                               | User     | Flange bolt tightening<br>(Please configure the corresponding wrench according to the selected bolt size) |
| Hex Screws (8-10mm) and Matching Washers | User     | Mounting flange bolt tightening<br>(Please select based on the actual furnace opening size)               |
| 17mm hex wrench                          | User     | Soft fuel line connection   |
| 5mm hex key                              | User     | Nozzle position adjustment  |
| Flathead screwdriver (No.1)              | User     | Controller terminal release<br>/ pump bleed screw   |
| 4mm hex key                              | Standard | Flange fixing<br>/ pump pressure adjustment<br>/ Damper adjustment  |
| Pressure gauge (0–20bar, G1/8)           | User     | Pump pressure monitoring  |
| Insulating tape                          | User     | Electrical insulation   |
| Oil-resistant sealant                    | User     | Fuel line sealing   |

### ▶ Burner Installation




- Secure flange and gasket to boiler interface.
- Align burner body; fasten with bolts.
- Connect fuel lines and power cables (follow wiring diagrams).

## Fuel System Connection



| System      | Scenario                           | Key Difference  | Pump Operation  |
|-------------|------------------------------------|---|---|
| Single-Pipe | Tank above burner level            | <ul style="list-style-type: none"> <li>No return line</li> <li>Manual bleeding MUST be performed during initial startup.</li> </ul> | <ul style="list-style-type: none"> <li>Remove internal bypass screw D, install blind plug.</li> </ul> |
| Double-Pipe | Tank below burner or kerosene fuel | <ul style="list-style-type: none"> <li>Supply + return lines</li> <li>Auto-circulation</li> </ul>                                   | <ul style="list-style-type: none"> <li>Keep internal bypass screw D, connect fuel line.</li> </ul>    |

### Pump Internal Adjustment



Tools Required:

- 4mm hex key (provided with burner)


Mandatory Requirement: ⚠

The return line MUST be installed above the tank's maximum liquid level to prevent siphoning backflow.

### 1. Bleeding Instructions

**Single-pipe system:** Bleed by opening pressure gauge port (G1/8), before initial startup until bubble-free fuel flows.

### 2. Installation Sequence



### 3. Leak Test

- (1) Open ball valve; run pump (no ignition); check for leaks.
- (2) If leaking, retighten or replace gasket.

### 4. Critical Installation Notes


- Installation sequence is NON-INTERCHANGEABLE Ball valve (flow control) → Filter (purification) → Flexible hose → Oil pump
- Gasket Requirement: Sealing washers MUST be installed at pump-flexible hose junctions. Omission causes leakage risks

### 5. Maintenance tips

- The filter should be cleaned once a month and the filter element replaced annually (refer to the "Service and Maintenance" P45 section)


## Electrical Wiring Diagrams

### Control Box (Career\* KYLOA24.171B27H电子式)



| Label | Component                      | Label | Component                     |
|-------|--------------------------------|-------|-------------------------------|
| A1    | Controller* KYLOA24.171B27H电子式 | P1    | Operation hour counter        |
| A2    | Thermostat                     | H1    | Fault indicator               |
| S3    | Power switch                   | H2    | Operation indicator           |
| R1    | Flame detector (photocell)     | F1    | Fuse                          |
| T1    | Ignition transformer           | X1    | 7-Pin Connector (Burner Side) |
| M1    | Burner motor                   | X2    | 7-Pin Connector (Boiler Side) |
| Y1    | Pump solenoid valve            |       |                               |


Control Box (Honeywell TF834E.3)



| Label | Component            | Label | Component                     |
|-------|----------------------|-------|-------------------------------|
| A1    | Controller TF834E.3  | P1    | Operation hour counter        |
| A2    | Thermostat           | H1    | Fault indicator               |
| S3    | Power switch         | H2    | Operation indicator           |
| R1    | Flame detector       | F1    | Fuse                          |
| T1    | Ignition transformer | X1    | 7-Pin Connector (Burner Side) |
| M1    | Burner motor         | X2    | 7-Pin Connector (Boiler Side) |
| Y1    | Pump solenoid valve  |       |                               |

Key Safety Configuration Specifications

Dual-Safety Thermostat



Design Principle:

Two independent thermal units wired in series:

- Primary: Operating temperature (e.g. 80°C)
- Safety: Trip temperature = Primary + 15-20°C (e.g. 95°C)

**Safety Logic:** Activates power cutoff when primary fails and temperature exceeds safety threshold.

Fuse Specifications

Critical Parameters:

- 10A

Violation Consequences:

- Controller burnout lead to fire

Fault Signal Light

Installation:

- On a conspicuous wall in the operating room (not the control box indicator light)
- Separate from control box indicators

Critical Function:

Immediate visual identification of E01-E10 faults to prevent cascading failures

Operation Signal Light

Status Indicators:

- Constant green = Normal operation
- Dark = System shutdown

Wiring:

- Career KYLOA24.171B27H Electronic Controller: terminals N and 8
- Honeywell TF834E.3 Controller: terminals 6 and 8

Maintenance Triggers:


- 500 hours: Oil pump filter cleaning
- 3000 hours: Nozzle mandatory replacement

Data Application:

Records total burner runtime for predictive maintenance

## Fuel Supply and Atomization Principles → Startup Preparation


### Working Principle



Fuel is pressurized to 10bar by the pump, forming a conical mist via mechanical atomization nozzle, fully mixing with air to create combustible mixture.

### Nozzle Selection & Thermal Power Optimization

Golden Rule for Nozzle Sizing:



- GPH Definition: Gallons/hour (1 GPH = 3.785 L/h @ 7bar)
- Critical Impact: Every +0.25 GPH ≈ +11kW power (@10bar)

### Nozzle Selection Reference Table

| GPH  | 7 bar |         | 8 bar |         | 9 bar |         | 10 bar |         | 11 bar |         | 12 bar |         | 13 bar |         | 14 bar |         |
|------|-------|---------|-------|---------|-------|---------|--------|---------|--------|---------|--------|---------|--------|---------|--------|---------|
|      | kg/h  | kW      | kg/h  | kW      | kg/h  | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      | kg/h   | kW      |
| 1.75 | 5.15  | 61/60   | 5.51  | 65/64   | 5.85  | 69/68   | 6.15   | 73/72   | 6.45   | 76/75   | 6.73   | 80/78   | 7.01   | 83/82   | 7.28   | 86/85   |
| 2.00 | 5.89  | 70/69   | 6.29  | 75/73   | 6.68  | 79/78   | 7.03   | 83/82   | 7.37   | 87/86   | 7.69   | 91/90   | 8.01   | 95/93   | 8.32   | 99/98   |
| 2.25 | 6.62  | 78/77   | 7.08  | 84/82   | 7.52  | 89/88   | 7.91   | 94/93   | 8.29   | 98/97   | 8.65   | 103/101 | 9.01   | 107/105 | 9.36   | 111/109 |
| 2.50 | 7.36  | 87/86   | 7.87  | 93/92   | 8.36  | 99/97   | 8.79   | 104/103 | 9.21   | 109/107 | 9.61   | 114/112 | 10.11  | 119/117 | 10.411 | 123/121 |
| 2.75 | 8.10  | 96/95   | 8.66  | 103/101 | 9.20  | 109/107 | 9.68   | 115/113 | 10.14  | 120/118 | 10.58  | 125/123 | 11.02  | 131/128 | 11.46  | 136/133 |
| 3.00 | 8.83  | 105/104 | 9.44  | 112/110 | 10.03 | 119/117 | 10.55  | 125/123 | 11.06  | 131/129 | 11.54  | 137/134 | 12.02  | 143/140 | 12.49  | 148/145 |
| 3.50 | 10.3  | 122/121 | 11.02 | 131/128 | 11.71 | 139/136 | 12.31  | 146/143 | 12.9   | 153/150 | 13.46  | 160/157 | 14.02  | 166/163 | 14.57  | 173/170 |
| 4.00 | 11.78 | 140/137 | 12.59 | 149/147 | 13.38 | 159/156 | 14.07  | 167/164 | 14.74  | 167/164 | 15.39  | 182/179 | 16.03  | 190/187 | 16.66  | 198/194 |
| 4.50 | 13.25 | 157/154 | 14.17 | 168/165 | 15.06 | 179/175 | 15.83  | 188/184 | 16.59  | 197/193 | 17.32  | 205/202 | 17.32  | 214/210 | 18.74  | 222/218 |

Notes:

- GPH: U.S. Gallons Per Hour. 1 GPH = 3.785 L/h (at 7 bar).
- Power Format: Diesel / Kerosene (e.g., 64/59 = 64 kW on diesel, 59 kW on kerosene).
- Calorific Value Basis:
  - Diesel: 11.86 kWh/kg
  - Kerosene: 11.75 kWh/kg (≈ 0.92 × Diesel value).
- Flow-Pressure Relationship: Flow rate is proportional to the square root of pressure.
- Formula:  $Q_2 = Q_1 \times \sqrt{P_2 / P_1}$
- Advisory: Nozzle selection must be adjusted based on actual conditions (furnace back pressure, flue draft, fuel quality). Actual power may vary ±5%.

## Initial Startup Operation

### Fuel System Check

- Single-pipe system:
  1. Remove the return screw → Install blind plug
  2. Open pressure gauge port
  3. Run oil pump until bubble-free fuel flows
- Double-pipe system: Keep return screw → Connect return line to tank top

### Pressure Adjustment


- Critical Notice: Oil pump factory preset is 10±0.5 bar. Minor adjustment is permitted ONLY for special installation conditions (e.g. extreme altitude/temperature) or after nozzle replacement. Unauthorized adjustment voids warranty!

### Adjustment Procedure

| Step | Action                  | Precision           | Safety Control                   |
|------|-------------------------|---------------------|----------------------------------|
| 1    | Adjust with 4mm hex key | ≤¼ turn/step        | Stabilize 30s after adjustment   |
|      | Clockwise               | +0.5bar/¼ turn      | Never exceed 14bar               |
|      | Counterclockwise        | -0.5bar/¼ turn      | Never below min. design pressure |
| 2    | Lock at 10±0.5bar       | Fluctuation ≤0.3bar | -                                |

### Environmental Compensation (Reference)

| Condition               | Pressure Adjustment | Basis                    |
|-------------------------|---------------------|--------------------------|
| Altitude >1000m         | +0.3bar/500m        | Atmospheric compensation |
| Oil temp <0°C           | +0.2bar/5°C         | Viscosity compensation   |
| Biofuel/ Kerosene usage | -0.3bar             | Reduce nozzle wear       |
| Fuel line >5m           | +0.5bar             | Pipeline loss            |




| Symbol | Function            | Interface Size           |
|--------|---------------------|--------------------------|
| S      | Suction             | G 1/4                    |
| R      | Return port         | G 1/4                    |
| E      | Nozzle outlet       | G1/8                     |
| P      | Pressure gauge      | G1/8                     |
| V      | Vacuum              | G1/8                     |
| P1     | Pressure Adjustment | Operate with 4mm hex key |
| H      | Filter              | -                        |


### ▶ Forced Draft & Air-Fuel Ratio → Ignition Prep

#### Initial Ignition Setup

##### Damper and Nozzle Collaborative Position Calibration



Damper Adjustment




Nozzle Position

Loosen screw (B) and adjust the position of the nozzle position with screw (A) for good combustion.

| Load Condition | Nozzle Position | Damper Position     | Flame Verification     |
|----------------|-----------------|---------------------|------------------------|
| High load      | Advance         | Gradual opening     | Bright white, no smoke |
| Low load       | Retract         | Gradual closing     | Orang-yellow, stable   |
| 50% load       | Default         | 50% open ("8" mark) | Smooth transition      |

## ▶ Ignition & Flame Stabilization → Initial Ignition

### 🌀 Working Principle



### 🌀 Standard Ignition Sequence

| Step | Action              | Verification      | Success Indicator          |
|------|---------------------|-------------------|----------------------------|
| 1    | Power ON            | Fan operation     | Yellow light flashing      |
| 2    | Pre-purge           | ≥10 sec           | Stable exhaust sound       |
| 3    | Electrode discharge | "Crackling" sound | Blue arc visible           |
| 4    | Fuel injection      | Diesel odor       | Oil mist visible           |
| 5    | Flame establishment | 10-sec hold       | Stable orange-yellow flame |

### 🌀 Troubleshooting Failed Ignition

| Failure                 | Immediate Action           | Root Cause Check                              |
|-------------------------|----------------------------|---|
| <b>No arc</b>           | Emergency stop → Wait 50s  | 1. Electrode wiring<br>2. Transformer output  |
| <b>Arc but no flame</b> | Emergency stop → Wait 50s  | 1. Oil pressure (≥8bar)<br>2. Nozzle clog     |
| <b>Explosion</b>        | Emergency stop → Ventilate | 1. Damper too closed<br>2. Insufficient purge |

#### Safety Protocol After Fault Reset:

Wait 50s after failure before restart. Ensure complete dissipation of residual fuel vapors in combustion chamber.

## 4. Operation & Maintenance

### ▶ Startup Procedure

#### Step 1: Pre-check

- Verify fuel level (≥1/3 tank)
- Confirm valves open, cables secure

#### Step 2: Power ON

- Turn on burner power switch, automatic execution sequence:
  - (1) Fan starts → Operates ≥10 sec for basic air supply
  - (2) Ignition electrodes discharge → Oil pump energized for fuel injection
  - (3) Enters continuous operation after flame stabilization

#### ➤ Controller indicator Lights:

| Light    | State     | Meaning  |   |
|----------|-----------|--|---|
| Green ●  | Steady ON | Normal operation:<br>Stable flame,<br>no system faults | -   |
| Red ●    | Steady ON | Fault<br>(check error code)                            | Check error code & resolve  |
| Yellow ● | Flashing  | Purging or staged<br>control mode active               | No intervention needed.<br>Automatically switches after<br>procedure completion |

Applicable ONLY to: Control Box (Career \*KYLOA24.171B27H电子式)

### ▶ Flame Adjustment & Safety Monitoring

- Normal Flame: Orange-yellow, no flickering/black smoke
- Abnormal Handling:
  - Flickering: Adjust damper or clean nozzle
  - Black smoke: Increase air supply
  - EMERGENCY: Cut off the power supply and oil circuit if red light activates

#### Optimum Combustion Adjustment Protocol

##### Load Increase Procedure:

1. **Damper:** Gradually increase opening (+1 notch/step)
2. **Nozzle position:** Slide backward 2-3 mm
3. **Verification:**
  - Flame: Bright white
  - Exhaust: Zero black smoke
4. **Stabilization:** Maintain operation for 30 sec after each adjustment

##### Load Decrease Procedure:


1. **Damper:** Gradually reduce opening (-1 notch/step)
2. **Nozzle position:** Slide forward 1-2 mm
3. **Verification:**
  - Flame: Orange-yellow
  - No flickering
4. **Stabilization:** Maintain operation for 30 sec after each adjustment

### ▶ Shutdown Procedure

1. Turn off main power switch
- For extended shutdown: Close main fuel valve

## 5. Service & Maintenance

### ▶ Ignition Electrode & Brake Plate Settings



| Identifier | Description                  | Dimension    | Remarks / Notes  |
|------------|------------------------------|--------------|--|
| A          | Ignition Electrode Gap       | 3.0 - 4.0 mm | Ensure stable spark (Spark must not strike brake plate)  |
| B          | Electrode to Nozzle Distance | 9.0 mm       | Affects flame root stability                             |
| C          | Electrode to Nozzle Tip      | 4.0 - 6.0 mm |  |
| D          | Brake Plate to Nozzle Tip    | 5.0 mm       | Ensures atomized fuel is ignited at the optimal position |

### ▶ Routine Maintenance Notes

- Clean oil filter regularly (every 1000 hours or monthly).
- Keep flame sensor clean to prevent false alarms.
- Check tank bottom for water/sediment monthly.

### ▶ Maintenance Schedule

| Component    | Daily                  | Monthly         | Yearly  |
|--------------|------------------------|-----------------|---------|
| Filter       | Leak check             | Clean           | Replace |
| Electrodes   | Spark check            | Clean carbon    | Replace |
| Nozzle       | -                      | Spray check     | Replace |
| Oil pressure | Check gauge at startup | Calibrate gauge | -       |

### ▶ Burner Internal Cleaning

- Clean fan impeller, electrode area, and nozzle residues.
- Wipe with soft cloth. Avoid damaging insulation components.

## 6. Troubleshooting

| Code | Symptom                  | Possible Cause   | Solution   |
|------|--------------------------|--|--|
| E01  | Ignition failure         | Low oil pressure,<br>Electrode misalignment                          | Check pump pressure<br>(10bar)   |
| E02  | Black smoke              | Air damper opening too<br>small, Nozzle clogged                      | Increase air damper opening,<br>Clean/replace nozzle. Check<br>damper/nozzle alignment |
| E03  | Frequent Shutdown        | Unstable flame signal  | Check sensor wiring<br>& control box   |
| E04  | No Fuel Injection        | Clogged fuel line/nozzle,<br>Pump failure,<br>Solenoid valve stuck   | Clean filter,<br>Service oil pump  |
| E05  | Excessive Noise          | Air damper too open,<br>Coupling shaft eccentricity,<br>Motor damage | Reduce damper opening,<br>Replace coupling assembly,<br>Replace motor                  |
| E06  | Damper Scale<br>Mismatch | Loose dial,<br>Worn linkage,<br>Faded markings                       | Tighten dial screws,<br>Replace worn linkage parts,<br>Re-mark scale                   |
| E07  | Abnormal pressure        | Pump wear,<br>Loose regulator valve,<br>Clogged filter               | Perform P44 calibration<br>procedure   |
| E08  | Oil Pressure >14 bar     | Over-tightened regulator<br>valve, Clogged return line               | Turn pressure regulator<br>counterclockwise,<br>Clean return line                      |
| E09  | Fan Power Failure        | Tripped circuit breaker  | Reset circuit breaker,<br>Check wiring   |
| E10  | Yellow Light On          | Control box program error  | Power cycle unit,<br>Service controller  |

## 7. Packing List

| No. | Item                  | Qty      |
|-----|-----------------------|----------|
| 1   | Burner                | 1        |
| 2   | Mounting flange       | 1        |
| 3   | Gasket                | 1        |
| 4   | Nozzle tool           | 1        |
| 5   | Fuel lines (1m Rp1/4) | 2        |
| 6   | Screws                | Assorted |
| 7   | 4mm hex key           | 1        |
| 8   | Filter                | 1        |
| 9   | Manual book           | 1        |

## 8.Parts Diagram

